

## Steel Mains Distribution

### AMF250S-1

#### Description

Three-phase auto mains fail (AMF) unit allows automatic connection of a secondary electrical supply to a load upon failure of the primary. Mechanically and electronically interlocked 4 Pole AC1 rated contactors supplying a common rated HDHC copper busbar system and load connection pads. No volt connection for remote Generator start (N/O & N/C). Auxiliary power supply for Generator battery charging/jacket water heater. 3 Position key switch for Auto, Test and Generator run. Supply availability neon's for visual representation of status. Incoming supply adjustable undervolt and time delay relays for setting of individual supply parameters. All equipment housed in a steel enclosure with internal and external brass earth bar. Complete unit mounted within a galvanised steel crash frame with forklift pockets.

#### Enclosure

Grey (RAL7035) textured powder coated Zintec steel construction with phosphate welds. Separate incoming and outgoing (with control gear) compartments with internal protection shrouds and external panel key lock doors. Aluminium gland plate. Assembled to IP55.

#### Connections

	Termination	Protection
<b>Input 1 (Mains)</b>	3P+N+E Hardwire	250A 4 Pole Contactor
<b>Input 2 (Generator )</b>	3P+N+E Hardwire	250A 4 Pole Contactor
<b>Outgoing (Load)</b>	3P+N+E Hardwire	N/A
<b>Aux</b>	32A 230V 1P+N+E Socket	32A 2 Pole 30mA RCBO

(All MCB's have C-Type trip curves. All RCD's and RCBO's are Type A)

#### Dimensions

H 1700mm x W 985mm x D 530mm

#### Weight

160kgs



#### RENTAL CENTRES

**Scotland & North** ide Rental Ltd, Unit 8 Shawfield Trade Park, Rutherglen, Glasgow. G73 1DB Tel: 0141 647 0850

**The Midlands** ide Rental Ltd, Unit 4A & D, Zone 2, Burntwood Business Park, Ring Road, Burntwood, Staffs. WS7 3JQ Tel: 01543 674 759

**The South** ide Rental Ltd, Unit 13 Thurrock Trade Park, Oliver Road, Grays, Essex. RM20 3AL Tel: 01708 863 963

